



HESTORE.HU

elektronikai alkatrész áruház

EN: This Datasheet is presented by the manufacturer.

Please visit our website for pricing and availability at www.hestore.hu.

Dear customer, thank you for purchasing our product. Please read the following instructions carefully and follow them to serve you safely and to your full satisfaction. This will prevent misuse, damage, or injury. The 1D56 simulates a switched on television by alternately turning on and off the colored lights on the LED panel.

The package contains:

- 1 pcs TV LED simulator
- 1 pcs Power cord with plug
- 1 pcs Instructions

BASIC INFORMATION

Model	1D56
Functional switch	- ON - on - OFF - off - DUSK+7HRS - after dark, the device will run for 7 hours. - DUSK +4HRS - after dark, the device will run for 4 hours.
Twilight sensor	- Do not overlap, otherwise DUSK+7HRS and DUSK +4HRS modes will not work.
Power input	- AC 100-240 V 50/60 Hz
LED panel	- 2 blue lights: If the device is set to DUSK+4HRS (dusk + 4 hours). - 3 green lights: The device is set to DUSK+7HRS (dusk + 7 hours).
Pedestal	- The tilting base allows you to adjust the device to the position of your choice.
Holes for mounting on the wall	- There are two mounting holes on the base so you can attach the device to a wall, for example.

WARNING

General safety instructions

Read the instructions carefully before use and keep them for future reference.

- The manufacturer shall not be liable for consequential damages, property damage, personal injury caused by failure to follow the safety instructions herein, or improper use of the product.
- Do not use the device for purposes other than those described in the

instructions.

- Do not use the device if any part is damaged.
- This device is intended for indoor use only. Do not use the device outdoors.
- Do not use the device in areas with high humidity, such as bathrooms and swimming pools.
- Do not use the device in the bath, shower, sink or other containers containing water.
- Do not overlap the equipment.
- Do not leave the device near flammable objects.

ELECTRICAL SAFETY

General safety instructions

- This product should only be disassembled by an authorized technician if necessary, otherwise you are exposing yourself to the risk of electric shock.
- If a fault occurs, disconnect the product from the electricity supply.
- Do not use the device if the power cord or power plug is damaged and contact a service centre or claim the product from your dealer.
- Before use, always check that the power supply voltage matches the voltage indicated on the equipment's label.
- Do not carry the device by holding the power cord.
- Do not immerse the device, power cord or plug in water or other liquids.
- Use a dry cloth for wiping.

The product has been issued with a CE declaration of conformity in accordance with the applicable regulations. On request from the manufacturer: info@solight.cz, or downloadable from www.solight.cz.



SOLIGHT

Solight Holding, s.r.o., Na Brně 1972, Hradec
Králové 500 06, Czech Republic.