



HESTORE.HU


elektronikai alkatrész áruház

EN: This Datasheet is presented by the manufacturer.

Please visit our website for pricing and availability at www.hestore.hu.

TMC2208

Product Introduction



TMC2208 is an ultra-quiet two-phase stepper motor drive chip, continuous drive current 1.4A, peak current 2A, voltage range 4.75V-36V, 256 subdivision. The flexible microPlyer interpolation unit provides up to 256 subdivisions, allowing perfect sinusoidal control even in systems with limited pulse frequencies; these are also designed because stealthChop2 ultra-quiet technology is widely used in 3D printing. Compatible with existing 3D printer electronics, eliminating the expensive costs of redesign. With a standard step/dir interface, it is easy to use. It can replace the original TMC2100, lower heat, especially for 3D printing market.

Features


- UART configuration interface (9600-500k Baud)
- Power tube built-in drive current 1.4A ,peak current 2A, voltage range 4.75V-36V
- Up to 256 native microsteps (without interpolation)
- CoolStep™ current dynamic adjustment technology, can save 70% of the energy
- stealthChop2 - faster motor acceleration/deceleration than stealthChop
- dcStep™, stallGuard2™ stall detection technology
- Automatic stealthChop and spreadCycle switchover depending on velocity
- Hardware compatible with StepStick and Pololu A4988 Stepper Driver
- Components on bottom PCB side for better heat emission
- Automatic standby current reduction
- SteaClthop mute technology
- spreadCycle - highly dynamic motor control chopper

Technical Specifications

Model	TMC2208
Interface	Step/Dir
Configuration	CFG Pins or UART
Native Microsteps	up to 1/256
microPlyer Microsteps	1/256
Logic Voltage (VIO)	3-5V
Motor Voltage (VM)	5.5-36V
Motor Phase Current max	1.2A RMS, 2.0A Peak
Internal V- Regulator	enabled
RDson	<=0.3 Ohm
stealthChop (quiet)	yes
spreadCycle	yes
coolStep	no
stallGuard	no
dcStep	no

Pin Functions


TMC2208 Motor Drive Pin Descriptions



Pin	Function
Power Supply	
GND	Ground
VM	Motor Supply Voltage
VIO	Logic Supply Voltage
Motor Outputs	
M1A	Motor Coil 1
M1B	Motor Coil 1
M2A	Motor Coil 2
M2B	Motor Coil 2
Control Inputs	
STEP	Step-Signal Input
DIR	Direction-Signal Input
TMC2208	
EN	Enable Motor Outputs: GND=on, VIO=off
MS1	Step-Configuration
MS2	Step-Configuration
PDN	UART and Auto Power Down Control: GND=on, VIO=off
CLK	Clock Input
DIAG	Diagnostics Output
INDEX	Index Output
VREF	Analog Reference Voltage


Interface Resources

Wiring Diagram



The TMC2208 outputs continuous motor current up to 1.4A and peak current up to 2A. Therefore, the reference voltage of the driver module should not exceed 1V. At the same time, the driver module must be dissipated, otherwise it will affect the life of the driver module.

Motor Current Setting



The best way to set the motor current is by measuring the voltage on the Vref pin (0...2.5V) and adjusting the voltage with the potentiometer. The maximum settable motor current is 1.77A RMS (0.11Ohm sense resistors), but the SilentStepSticks can only be used up to 1.2A RMS.

$$I_{rms} = (V_{ref} * 1.77A) / 2.5V = V_{ref} * 0.71$$

$$V_{ref} = (I_{rms} * 2.5V) / 1.77A = I_{rms} * 1.41 = I_{max}$$

Vref -> Voltage on Vref pin

I_{rms} -> RMS (Root Mean Square) current per phase (I_{rms} = I_{max} / 1.41)

I_{max} -> Maximum current per phase (I_{max} = I_{rms} * 1.41)

1. Vref measures Gnd and the voltage at the middle of the potentiometer.
2. Do not connect the motor when measuring the voltage, otherwise it is easy to burn the driver.
3. Power should be connected when measuring voltage, do not just connect USB power supply.
4. **Please pay special attention to directions!**

Micro-stepping

MS2(-)	MS1(-)	Steps(-)	Interpolation(-)	Mode(-)
GND	VIO	½	1/256	stealthChop2
VIO	GND	¼	1/256	stealthChop2
GND	GND	⅙	1/256	stealthChop2
VIO	VIO	1/16	1/256	stealthChop2

Setting Method

With the TMC2208 Configurator you can change the settings and program the OTP (One-Time-Programmable) memory of a Trinamic TMC2208 via the UART interface.

To run the program:


1. Install ScriptCommunicator
2. Download TMC2208.scez
3. Start the TMC2208.scez file with the ScriptCommunicator: ScriptCommunicator TMC2208.scez
4. Choose the right serial port and click Connect
5. Modifications in the Configurator are directly transmitted

Tip


The OTP bits can be programmed only one time. If you enable spreadCycle then TOFF cannot be 0 (null).

Hardware Connection

Standalone Connection



In-Circuit / On-Board Connection



You can use every RS232 serial adapter with 0-5V logic levels (e.g. FTDI-Breakout) and the SilentStepStick Tester/Programmer can be used as connection adapter.

The jumper next to the PDN_UART pin has to be closed on the TMC2208 SilentStepStick to enable the pin access via the pin header.